

2 For your safety

The Safety chapter first explains the safety symbols used in the documentation and their meanings. They contain fundamental safety instructions that are essential for the avoidance of personal injuries and damage to property.

Exclusion of liability

Beckhoff shall not be liable in the event of non-compliance with this documentation and thus the use of the battery packs outside the documented operating conditions.

2.1 Description of safety symbols

The following safety symbols are used in these operating instructions. In order to avoid personal injuries and damage to property, read and follow the safety and warning notices.

Warning of personal injuries:

⚠ DANGER
Disregarding the safety notice will lead to death or serious injuries.
⚠ WARNING
Disregarding the safety notice may lead to death or serious injuries.
⚠ CAUTION
Disregarding the safety notice may lead to minor injuries.

Warning of damage to property:

NOTICE
Disregarding the notice may lead to damage to property.

2.2 Intended use

The battery pack is designed for DIN rail mounting in control cabinets of machine and system engineering. It serves PCs with 24 V power supply unit and integrated C9900-U209 UPS as external energy storage. The battery pack is designed for PCs with Intel Atom® or Celeron®-ULV-827E 1.4 GHz processor.

The specified limits for technical data must be adhered to.

The battery pack can be used within the documented operating conditions.

Improper use

Do not use the battery pack outside the documented operating conditions.